

Disable function in optical modules



Overview

By default, a large number of alarm messages will be generated if the module is verified as non-H3C original.

Key Takeaways

You can disable an optical module either manually or automatically to stop laser emission or transmission, using device-specific commands or settings. Manual Laser or Transmission Disable

- Huawei Devices: To manually disable the optical module laser, access the system interface and run the command `laser turn-off`. This immediately stops the laser but will interrupt services on the interface, so it should only be done when the interface is not actively transmitting data. Manual enabling can be done later with `laser turn-on` to check service recovery .

- Intel X710/XL710/X722 SFP Modules: On Linux systems using the i40e driver, you can disable the TX port (laser transmission) by first setting the NIC down with `ifconfig` down and ensuring the SFP module supports TX disable. Additionally, set the private flag `link-down-on-close` to ON to maintain the TX-disabled state after reboot .

Automatic Laser Disable

- Huawei Devices: You can configure the optical module to automatically disable the laser when a link failure is detected using the command `laser autoshutdown enable`. Optionally, you can set intervals for automatic checks with `laser auto-shutdown-interval { open open-value | close close-value }` . This prevents accidental exposure to the laser during troubleshooting.

Safety Precautions

- Always power on the device and ensure it passes self-checks before disabling the module .

- Avoid looking directly into active fiber ports, even if the module is low-power or Class 1 .

- Disabling the laser or TX port interrupts network services, so plan maintenance accordingly .

Managing Alerts

- On some devices, such as F5 BIG-IP, disabling an optical module may trigger alerts like “Unsupported Optic.” You can suppress these alerts by editing the alert configuration file (/etc/alertd/alert.conf) and backing up the original configuration . By following these steps, you can safely disable an optical module for maintenance, troubleshooting, or compliance with safety protocols while minimizing network disruption.

Article Content

Disabling the Optical Module Alarm Function

You can disable the alarm function for an optical module to prevent the optical module from reporting alarms when its optical power

Disabling the Optical Module Alarm Function

You can disable the alarm function for an optical module to prevent the optical module from reporting alarms when its optical power

How To Turn Off Alarms For Third-Party Modules On Huawei Switches

By default, numerous alarm messages will be generated when a non-original Huawei module is used. Huawei

How to disable the optical module

This feature provides the ability to disable and re-enable an optical module through CLI, which simulates online insertion and removal

How To Turn Off Alarms For Third-Party Modules On H3C Switches

By default, a large number of alarm messages will be generated if the module is verified as non-H3C original. H3C

port-alarm disable optical-module

Some optical modules can continue working properly when the actual optical power is at the warning level. You can disable the

How to set X710, XL710, X722 SFP Port Tx disable function

Content: 1. TX disable function means SFP module's TX port to disable laser signal after key-in "ifconfig down" 2. By Intel

ALM-135471444 hwOpticalUnauthorized_Common Alarms_V600

If the optical modules are early delivered from Huawei, run the transceiver non-certified-alarm disable command to

How to set NMC-6003 & FWA-6003L (chip:E810) QSFP Port Tx

When remote system's needs to enable NMC-6003/6003L (Chip: E810) TX disable function, it has to check following items. 2.1

Interface and Hardware Component Configuration Guide for Cisco

This feature provides the ability to disable and re-enable an optical module through CLI, which simulates online

Everything You Need to Know About Optical Modules

Optical modules are electronic devices used in communication systems to transmit optical

Fundamentals of an Optical Module

Fundamentals of an Optical Module As an important part of fiber-optic communication, an optical module is a photoelectric converter

Configuring the Alarm Function for Non-Huawei-Certified Switch Optical ...

These optical modules can still be used to protect customer investment. In this case, you can disable the alarm

What is the use of CDR clock data recovery in optical modules?--ETU ...

In high-speed fiber-optic communication,data centers,and long-haul transmission systems,signal integrity is critical.

Configure Optical Modules

Configure Optical Modules This chapter describes how to configure the Optical Amplifier Module and Protection Switching Module

Enabling or Disabling the Optical Module Laser

To configure the optical module to disable the laser automatically, run the laser autosutdown enable command. (Optional) To

The Most Comprehensive Guide Of Optical Modules

Explore the ultimate guide to optical modules. Learn types, functions, performance metrics

FS Community

We would like to show you a description here but the site won't allow us.

Optical Module: Typical Optical Module Troubleshooting Procedure

If the optical module is faulty, replace it with the spare part. If the fault is caused by the configuration or environment, advise the

What Is an Optical Module and Its FAQs (V200)

What Is an Optical Module and Its FAQs (V200) Describes what an optical module is and FAQs, including the fundamentals,

Configuration Guide for Cisco NCS 1001, IOS XR Release 7.9.x

This chapter describes how to configure the Optical Amplifier Module and Protection Switching Module (PSM).

How to set X710, XL710, X722 SFP Port Tx disable function

Content: 1. TX disable function means SFP module's TX port to disable laser signal after key-in "ifconfig down" 2. By Intel

The Key External Components of Optical Modules

In this blog, we'll explore the core structure of an optical transceiver, explaining the function of each part and how they

FO Exclusive: Xi Jinping's Military Purge Signals Rising Paranoia in

FO Exclusive: Xi Jinping's Military Purge Signals Rising Paranoia in China In this section of the January 2026 episode

Configuration Guide for Cisco NCS 1001, IOS XR Release 7.9.x

This chapter describes how to configure the Optical Amplifier Module and Protection Switching Module (PSM).

How to set X710, XL710, X722 SFP Port Tx disable function

Content: 1. TX disable function means SFP module's TX port to disable laser signal after key-in "ifconfig down" 2. By Intel

The Key External Components of Optical Modules

In this blog, we'll explore the core structure of an optical transceiver, explaining the function of each part and how they

FO Exclusive: Xi Jinping's Military Purge Signals Rising Paranoia in

FO Exclusive: Xi Jinping's Military Purge Signals Rising Paranoia in China In this section of the January 2026 episode

Why Are Alarms About Optical Modules That Are Not Certified for

Therefore, alarms about optical modules that are not certified for Huawei Ethernet switches are generated. You can run

Configuration Guide for Cisco NCS 1001, IOS XR Release 7.10.x

This chapter describes how to configure the Optical Amplifier Module and Protection Switching Module (PSM).

How to set NMC-6003 & FWA-6003L (chip:E810) QSFP Port Tx disable function

Purpose: It list How to enable E810 QSFP TX_disabled function by Linux ice driver for customer reference, Target Audience: For

ALM-3276800044 An Optical Module Installed on the Device Is ...

If this optical module was delivered from Huawei earlier, run the transceiver phony-alarm-disable command to disable

How To Turn Off Alarms For Third-Party Modules On Huawei Switches

Huawei switches perform authentication on inserted optical modules. By default, numerous alarm messages will be

Configuring the Alarm Function for Non-Huawei-Certified Optical Modules ...

When these optical modules are used on devices, the devices will also generate non-Huawei-certified optical module

Configuring the Alarm Function for Optical Modules

You can configure the alarm thresholds for the power, temperature, current, and voltage of optical modules, and the interval at which

what is the function of optical modules

The function of optical modules is to bridge different network components while transmitting and receiving data.

Guns for Sale

Find a full range of guns for sale at Hinterland Outfitters including handguns, rifles, and shotguns. We carry all the top brands of

Optical Module Coding Explained

Optical Module Coding is the digital key ensuring network device compatibility and stability by verifying module specs,

Everything You Need to Know About Optical Modules

Optical modules are electronic devices used in communication systems to transmit optical

Fundamentals of an Optical Module

Fundamentals of an Optical Module As an important part of fiber-optic communication, an optical module is a photoelectric converter

Configuring the Alarm Function for Non-Huawei-Certified Switch Optical ...

These optical modules can still be used to protect customer investment. In this case, you can disable the alarm

What is the use of CDR clock data recovery in optical modules?--ETU ...

In high-speed fiber-optic communication,data centers,and long-haul transmission systems,signal integrity is critical.

Configure Optical Modules

Configure Optical Modules This chapter describes how to configure the Optical Amplifier Module and Protection Switching Module

Enabling or Disabling the Optical Module Laser

To configure the optical module to disable the laser automatically, run the laser autosutdown enable command. (Optional) To

The Most Comprehensive Guide Of Optical Modules

Explore the ultimate guide to optical modules. Learn types, functions, performance metrics

FS Community

We would like to show you a description here but the site won't allow us.

Optical Module: Typical Optical Module Troubleshooting Procedure

If the optical module is faulty, replace it with the spare part. If the fault is caused by the configuration or environment, advise the

What Is an Optical Module and Its FAQs (V200)

What Is an Optical Module and Its FAQs (V200) Describes what an optical module is and FAQs, including the fundamentals,

Configuration Guide for Cisco NCS 1001, IOS XR Release 7.9.x

This chapter describes how to configure the Optical Amplifier Module and Protection Switching Module (PSM).

How to set X710, XL710, X722 SFP Port Tx disable function

Content: 1. TX disable function means SFP module's TX port to disable laser signal after key-in "ifconfig down" 2. By Intel

The Key External Components of Optical Modules

In this blog, we'll explore the core structure of an optical transceiver, explaining the function of each part and how they

FO Exclusive: Xi Jinping's Military Purge Signals Rising Paranoia in

FO Exclusive: Xi Jinping's Military Purge Signals Rising Paranoia in China In this section of the January 2026 episode

Disabling the Optical Module Alarm Function

You can disable the alarm function for an optical module to prevent the optical module from reporting alarms when its optical power

Disabling the Optical Module Alarm Function

You can disable the alarm function for an optical module to prevent the optical module from reporting alarms when its optical power

How To Turn Off Alarms For Third-Party Modules On Huawei Switches

By default, numerous alarm messages will be generated when a non-original Huawei module is used. Huawei

How to disable the optical module

This feature provides the ability to disable and re-enable an optical module through CLI, which simulates online insertion and removal

How To Turn Off Alarms For Third-Party Modules On H3C Switches

By default, a large number of alarm messages will be generated if the module is verified as non-H3C original. H3C

port-alarm disable optical-module

Some optical modules can continue working properly when the actual optical power is at the warning level. You can disable the

How to set X710, XL710, X722 SFP Port Tx disable function

Content: 1. TX disable function means SFP module's TX port to disable laser signal after key-in "ifconfig down" 2. By Intel

ALM-135471444 hwOpticalUnauthorized_Common Alarms_V600

If the optical modules are early delivered from Huawei, run the transceiver non-certified-alarm disable command to

How to set NMC-6003 & FWA-6003L (chip:E810) QSFP Port Tx

When remote system's needs to enable NMC-6003/6003L (Chip: E810) TX disable function, it has to check following items. 2.1

Interface and Hardware Component Configuration Guide for Cisco

This feature provides the ability to disable and re-enable an optical module through CLI, which simulates online

Disabling the Optical Module Alarm Function

You can disable the alarm function for an optical module to prevent the optical module from reporting alarms when its optical power

Disabling the Optical Module Alarm Function

You can disable the alarm function for an optical module to prevent the optical module from reporting alarms when its optical power

How To Turn Off Alarms For Third-Party Modules On Huawei Switches

By default, numerous alarm messages will be generated when a non-original Huawei module is used. Huawei

How to disable the optical module

This feature provides the ability to disable and re-enable an optical module through CLI, which simulates online insertion and removal

How To Turn Off Alarms For Third-Party Modules On H3C Switches

By default, a large number of alarm messages will be generated if the module is verified as non-H3C original. H3C

port-alarm disable optical-module

Some optical modules can continue working properly when the actual optical power is at the warning level. You can disable the

How to set X710, XL710, X722 SFP Port Tx disable function

Content: 1. TX disable function means SFP module's TX port to disable laser signal after key-in "ifconfig down" 2. By Intel

ALM-135471444 hwOpticalUnauthorized_Common Alarms_V600

If the optical modules are early delivered from Huawei, run the transceiver non-certified-alarm disable command to

How to set NMC-6003 & FWA-6003L (chip:E810) QSFP Port Tx

When remote system's needs to enable NMC-6003/6003L (Chip: E810) TX disable function, it has to check following items. 2.1

Interface and Hardware Component Configuration Guide for Cisco

This feature provides the ability to disable and re-enable an optical module through CLI, which simulates online

Contact Us

Continue your research online:

Website: <https://alfa-pro.co.za>

Technical inquiry: <https://alfa-pro.co.za/contact.html>

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

