RRU also needs to be plugged into a light module

Overview

RRU Installation and Hardware GuideThe document provides instructions for installing RRU, DBS, BTS and TMA equipment and their associated cables. It descri.

Key Takeaways

Yes, the RRU must be connected to a light (optical) module to enable communication with the BBU/DU and ensure proper operation.

Optical Connection Requirement

The RR

U, such as Huawei's RRU5517t or similar models, includes an optical fiber port at its bottom panel, which is used to connect the RRU to the baseband unit (BBU) or distributed unit (DU) via fiber optic cables. This connection is essential for transmitting digital baseband signals between the RRU and the BBU/DU. Without plugging the optical module into the RRU, the unit cannot send or receive data, and the system will not function correctly.

Installation Considerations

Use field optical cables designed for outdoor environments, which are tension-resistant, flexible, oil- and wear-resistant, and flame-retardant. Quick-lock connectors are typically used to plug the fiber into the RRU's optical module, allowing for secure and repeatable connections. Ensure the optical module is powered on and properly seated; an unpowered or disconnected optical module will prevent the RRU from communicating with the BBU/DU.

© 2026 ALFA PRO COMMUNICATION SYSTEMS (Pty) Ltd - All rights reserved

The optical connection is part of the RRU's bottom panel ports, along with RF and power ports, and must be installed according to the manufacturer's guidelines to maintain system reliability.

Auxiliary Devices and Monitoring

Some RR

Us work with monitoring extension boxes (MEBs) or other auxiliary devices, which may also interface through the optical module for status reporting and control signals. Proper optical connection ensures that these monitoring functions operate correctly.

Summary

To operate an RRU correctly: Connect the optical fiber cable to the RRU's optical module. Ensure the module is powered and secured. Verify connectivity with the BBU/DU and any auxiliary monitoring devices.

Failing to plug the RRU into the light module will prevent data transmission and may disrupt the base station's operation.

Article Content

RRU Installation and Hardware Guide

The document provides instructions for installing RRU, DBS, BTS and TMA equipment and their associated cables. It describes the appearance and functions of the RRU, and outlines the steps for

HUAWEI RRU USER MANUAL Pdf Download | ManualsLib

When the temperature of the battery exceeds 60 C, check whether there is acid overflow. If acid overflow occurs, handle the acid immediately.

HUAWEI RRU3804 USER MANUAL Pdf Download

The optical module provides an interface for optical-electrical conversion, thus enabling transmission through optical fibers between the RRU and other devices.

RRU5517t Hardware Description

Explore the Huawei RRU5517t Hardware Description. This guide covers RRU introduction, functions, technical specifications, ports, indicators, cables, and auxiliary devices for SRAN17.1 and later versions.

Huawei Technologies Remote Radio Unit : User''s Manual

© 2026 ALFA PRO COMMUNICATION SYSTEMS (Pty) Ltd - All rights reserved

Procedure Step 1 Lower the pullers of two optical modules, insert one optical module into the CPRI0 port on the RRU and the other optical module into the CPRI port on the BBU, and raise the pullers, as

RRU5505&RRU5505N Installation Guide | PDF | Electrical Connector ...

After removing dustproof caps from the optical module and optical fiberconnector, insert the optical fiber into the optical module immediately (withinone minute) to avoid pollution of the optical module or

DBS3900 RRU3252, RRU3256 Hardware Description | Manualzz

This document provides reference for planning and deploying an RRU3252/RRU3256 (referred to as RRU in this document). It presents the exterior and describes the ports, functions, cable types,

Huawei Technologies Remote Radio Unit : Installation Guide

Figure 3-12 RRU installed on a wall 3.5 Installation Clearance Requirements of an RRU This section describes the requirements for the installation clearance of a single RRU and multiple RRUs and the

RRU3252/RRU3256 Hardware Maintenance Guide

An optical module provides optical-electrical conversion ports, enabling optical transmission between an RRU and other devices. Optical cables inserted into an optical module must be removed before the

Microsoft PowerPoint

At the end of the DC RRU power cable connected to the DCDU-03B, you need to make the shielding layer of the power cable into an OT terminal, and then connect the OT terminal to the PGND terminal

RRU3220 Installation Guide (V100R002C00

RRU3220 V100R002C00 Installation Guide Issue: 01 Date: 2010-05-20 HUAWEI TECHNOLOGIES CO., LTD. fContents Installation Tools 2 Installation Options 3 Dimensions and Installation Clearance 4

Installation Guide

Lower the pullers of two optical modules, insert one optical module into the CPRI0 port on the RRU and the other optical module into the CPRI port on the BBU, and raise the pullers, as shown in Figure 7-25.

Remote Radio Unit

© 2026 ALFA PRO COMMUNICATION SYSTEMS (Pty) Ltd - All rights reserved

Remote Radio Unit (RRU) - an enclosed radio transceiver with the baseband and control interfaces exposed to allow for remote control. Usually, these devices are used extensively by telecoms, but

RRU5935E Hardware Description

Hardware description for RRU5935E remote radio unit. Details exterior, functions, ports, specs, cables, and RF connections. For installation and maintenance.

What is RRU, BBU and Antenna?

Refreshing some basic concepts. BBU (Baseband Unit): manages the whole base station, including operating maintenance as will as signal processing. RRU (Remote Radio Unit):

What is a GFCI Outlet? Full Guide

Your hair dryer is plugged into a GFCI outlet. which is faithfully comparing current going to and from the dryer. The GFCI, seeing the imbalance, trips; and trips

Remote Radio Units (RRU)

These products are engineered for use in robotics, control panels, motion control systems, lighting, building systems, HVAC, appliances, and an array of safety-critical applications. We also offer an

RRU Installation and Cable Guidelines

The RRU installation process involves installing three RRUs, connecting antenna jumper cables, power cables, optical cables and grounding cables. Detailed steps are provided for installing each cable

Contact Us

Continue your research online:

Website: https://alfa-pro.co.za
Technical inquiry: https://alfa-pro.co.za/contact.html

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

© 2026 ALFA PRO COMMUNICATION SYSTEMS (Pty) Ltd - All rights reserved