


Configuring SSH for H3C Core Switches



Overview

Support As shown in Figure 1-28, establish an SSH connection between Switch A (SSH Client) and Switch B (SSH Server) for Support In this video, I have expl.

Key Takeaways

To configure SSH on an H3C switch, you must enable the SSH/Stelnet server, generate local key pairs, configure user authentication, and permit SSH login on the VTY lines. These steps follow the official H3C SSH configuration guides.1. Basic SSH Server Configuration (Password Authentication)Step-by-step

-

Enter system view

system-view

-

Generate RSA key pair (Required for SSH server operation)

rsa local-key-pair create

-

Enable SSH (Stelnet) server

stelnet server enable

-

Enable SFTP/SCP if needed

sftp server enable
scp server enable

-

Create an SSH user

local-user admin password simple YourPassword service-type ssh

-

Configure VTY lines for SSH login

line vty 0 4 authentication-mode scheme protocol inbound ssh

-

Assign an IP address to the management VLAN/interface

interface Vlan-interface 1 ip address 192.168.1.1 255.255.255.0

Connect from client

ssh admin@192.168.1.1 2. SSH Server Configuration (Public Key Authentication)Steps

-

Generate local key pair

rsa local-key-pair create

-

Import client public key

public-key-code begin
public-key-code end

-

Bind public key to user

ssh user admin service-type ssh
ssh user admin authentication-type publickey
ssh user admin public-key client-key

-

Enable SSH server

stelnet server enable

-

Configure VTY lines

line vty 0 4 authentication-mode scheme protocol inbound ssh

Public key configuration details are documented in H3C's SSH configuration guides.

3. Useful Optional Settings

Change SSH port

ssh server port 2222 Set SSH version (H3C uses SSH2 by default)

ssh server compatible-ssh1 disable Limit algorithms (Suite B / security hardening)

ssh server algorithms cipher aes256-ctr

(Algorithm configuration described in H3C security guide.)

4. Verification Commands

display ssh server status
display ssh user
display ssh session
display rsa local-key-pair public

5. Example Complete Configuration (Password Authentication)

```
system-view
rsa local-key-pair create
telnet server enable
local-user admin password simple MyPass123 service-type ssh
line vty 0 4
 authentication-mode scheme
 protocol inbound ssh
interface Vlan-interface 1
 ip address 10.10.10.1 255.255.255.0
```

Summary
H3C SSH configuration requires enabling the SSH/STELNET server, generating key pairs, creating an SSH user, and allowing SSH on VTY lines. These steps follow the official H3C configuration guides for S5500, S6520, and campus switches.

Article Content

Support

As shown in Figure 1-28, establish an SSH connection between Switch A (SSH Client) and Switch B (SSH Server) for

Support

In this video, I have explained and verified the Telnet & SSH configuration on an H3C Switch (Model 6520). The same

Basic CLI Commands on H3C Switch

Learn how to create users, VLANs, enable Telnet and SSH, configure Spanning Tree Protocol, enable

Chapter 1 SSH Configuration. H3C S5100-8P-SI, S5100-26C-EI

As shown in Figure 1-32, establish an SSH connection between Switch A (SSH Client) and Switch B (SSH Server) for secure data

H3C switch HTTP access configuration complete guide: from ...

Now, many H3C switches and routers come with a WEB graphical interface by default, which makes operation and

H3C S5500-EI SERIES OPERATION MANUAL Pdf Download

View and Download H3C S5500-EI Series operation manual online. S5500-EI Series switch pdf manual download. Also for: S3610

H3C S3600 SERIES OPERATION MANUAL Pdf Download | ManualsLib

Configuration procedure The configuration procedure varies with login authentication modes. However, you must complete the

H3C Campus Fixed-Port Switches Web-Based Configuration Guide

The H3C Campus Fixed-Port Switches Web-Based Configuration Guide describes the web functions of the H3C Campus Fixed-Port

H3C S1600V2 Switch Series Web Configuration Guide

After you configure broadcast/unknown unicast/unknown multicast storm control on an interface, if the broadcast/unknown

H3C S3600 SERIES OPERATION MANUAL Pdf Download | ManualsLib

View and Download H3C S3600 Series operation manual online. SSH Terminal Service, Ethernet Switches. S3600 Series network

H3C S5500-EI SERIES OPERATION MANUAL Pdf Download

Operation Manual – SSH H3C S5500-EI Series Ethernet Switches Chapter 1 SSH Configuration 1.2.5 Configuring a Client Public

download.h3c

We would like to show you a description here but the site won't allow us.

Support

As shown in Figure 2-1, an SSH connection is established between Switch A and Switch B. Switch A, an SFTP client, uses the

Support

For more information about login methods and user interfaces, see H3C S10500X Switch Series Fundamentals Configuration Guide.

Support

As shown in Figure 2-1, an SSH connection is established between Switch A and Switch B. Switch A, an SFTP client, uses the

Support

On the switch, you can configure Telnet or SSH for remote access through Ethernet ports. You manage console login users at AUX

H3C Campus Fixed-Port Switches Web-Based Configuration Guide

The H3C Campus Fixed-Port Switches Web-Based Configuration Guide describes the web functions of the H3C Campus Fixed-Port

Support

Configuring SSH Overview Secure Shell (SSH) is a network security protocol. Using encryption and authentication, SSH can

Support

Configuring SSH About SSH Secure Shell (SSH) is a network security protocol. Using encryption and authentication, SSH can

Support

Introduction The following information provides examples for using SSH to implement secure remote access or file management.

Support

Home Support Configure & Deploy Configuration Examples H3C Fixed Port Campus Switches Configuration Examples-B70D029

Support

The SSH client authentication method is password in this configuration procedure. For more information about SSH and publickey

Support

Overview Secure Shell (SSH) is a network security protocol. Using encryption and authentication, SSH can implement secure remote

Support

Introduction The following information provides examples for using SSH to implement secure remote access or file management.

Support

Home Support Configure & Deploy Configuration Examples H3C Fixed Port Campus Switches Configuration Examples-B70D029

Support

The SSH client authentication method is password in this configuration procedure. For more information about SSH and publickey

Support

Overview Secure Shell (SSH) is a network security protocol. Using encryption and authentication, SSH can implement secure remote

H3C Switch Command Mastery: Streamlined Configuration

In today's fast-paced network environments, H3C switches form the backbone of enterprise connectivity. While many administrators

Support

As shown in Figure 1-4, establish an SSH connection between the host (SSH client) and the switch (SSH server) for secure data

Support

H3C Campus Fixed-Port Switches CLI-Based Quick Start Configuration Guide -6W102

Support

Configuring SSH About SSH Secure Shell (SSH) is a network security protocol. Using encryption and authentication, SSH can

H3C switch HTTP access configuration complete guide: from ...

In the Web management interface, you can easily perform various configuration and management operations on the

Support

Configuring SSH About SSH Secure Shell (SSH) is a network security protocol. Using encryption and authentication, SSH can

Support

Configuring SSH About SSH Secure Shell (SSH) is a network security protocol. Using encryption and authentication, SSH can

Support

Configuring SSH Overview Secure Shell (SSH) is a network security protocol. Using encryption and authentication, SSH can

Support

This section provides the SSH server configuration procedure used when the SSH client authentication method is password. For

Support

Prerequisites Before logging in to the device through the console port, prepare the following tools: · Console cable—An eight-core

[H3C S3600 SERIES OPERATION MANUAL Pdf Download | ManualsLib](#)

View and Download H3C S3600 Series operation manual online. SSH Terminal Service, Ethernet Switches. S3600 Series network

[H3C S5500-EI SERIES OPERATION MANUAL Pdf Download](#)

Operation Manual – SSH H3C S5500-EI Series Ethernet Switches Chapter 1 SSH Configuration 1.2.5 Configuring a Client Public

[download.h3c](#)

We would like to show you a description here but the site won't allow us.

Support

As shown in Figure 2-1, an SSH connection is established between Switch A and Switch B. Switch A, an SFTP client, uses the

Support

For more information about login methods and user interfaces, see H3C S10500X Switch Series Fundamentals Configuration Guide.

Support

As shown in Figure 2-1, an SSH connection is established between Switch A and Switch B. Switch A, an SFTP client, uses the

Support

On the switch, you can configure Telnet or SSH for remote access through Ethernet ports. You manage console login users at AUX

[H3C Campus Fixed-Port Switches Web-Based Configuration Guide](#)

The H3C Campus Fixed-Port Switches Web-Based Configuration Guide describes the web functions of the H3C Campus Fixed-Port

Support

Configuring SSH Overview Secure Shell (SSH) is a network security protocol. Using encryption and authentication, SSH can

Support

Configuring SSH About SSH Secure Shell (SSH) is a network security protocol. Using encryption and authentication, SSH can

Support

Introduction The following information provides examples for using SSH to implement secure remote access or file management.

Support

Home Support Configure & Deploy Configuration Examples H3C Fixed Port Campus Switches Configuration Examples-B70D029

Support

The SSH client authentication method is password in this configuration procedure. For more information about SSH and publickey

Support

Overview Secure Shell (SSH) is a network security protocol. Using encryption and authentication, SSH can implement secure remote

Support

As shown in Figure 1-28, establish an SSH connection between Switch A (SSH Client) and Switch B (SSH Server) for

Support

In this video, I have explained and verified the Telnet & SSH configuration on an H3C Switch (Model 6520). The same

Basic CLI Commands on H3C Switch

Learn how to create users, VLANs, enable Telnet and SSH, configure Spanning Tree Protocol, enable

Chapter 1 SSH Configuration. H3C S5100-8P-SI, S5100-26C-EI

As shown in Figure 1-32, establish an SSH connection between Switch A (SSH Client) and Switch B (SSH Server) for secure data

H3C switch HTTP access configuration complete guide: from ...

Now, many H3C switches and routers come with a WEB graphical interface by default, which makes operation and

[H3C S5500-EI SERIES OPERATION MANUAL Pdf Download](#)

View and Download H3C S5500-EI Series operation manual online. S5500-EI Series switch pdf manual download. Also for: S3610

[H3C S3600 SERIES OPERATION MANUAL Pdf Download | ManualsLib](#)

Configuration procedure The configuration procedure varies with login authentication modes. However, you must complete the

[H3C Campus Fixed-Port Switches Web-Based Configuration Guide](#)

The H3C Campus Fixed-Port Switches Web-Based Configuration Guide describes the web functions of the H3C Campus Fixed-Port

[H3C S1600V2 Switch Series Web Configuration Guide](#)

After you configure broadcast/unknown unicast/unknown multicast storm control on an interface, if the broadcast/unknown

Support

As shown in Figure 1-28, establish an SSH connection between Switch A (SSH Client) and Switch B (SSH Server) for

Support

In this video, I have explained and verified the Telnet & SSH configuration on an H3C Switch (Model 6520). The same

[Basic CLI Commands on H3C Switch](#)

Learn how to create users, VLANs, enable Telnet and SSH, configure Spanning Tree Protocol, enable

[Chapter 1 SSH Configuration. H3C S5100-8P-SI, S5100-26C-EI](#)

As shown in Figure 1-32, establish an SSH connection between Switch A (SSH Client) and Switch B (SSH Server) for secure data

[H3C switch HTTP access configuration complete guide: from ...](#)

Now, many H3C switches and routers come with a WEB graphical interface by default, which makes operation and

[H3C S5500-EI SERIES OPERATION MANUAL Pdf Download](#)

View and Download H3C S5500-EI Series operation manual online. S5500-EI Series switch pdf manual download. Also for: S3610

H3C S3600 SERIES OPERATION MANUAL Pdf Download | ManualsLib

Configuration procedure The configuration procedure varies with login authentication modes. However, you must complete the

H3C Campus Fixed-Port Switches Web-Based Configuration Guide

The H3C Campus Fixed-Port Switches Web-Based Configuration Guide describes the web functions of the H3C Campus Fixed-Port

H3C S1600V2 Switch Series Web Configuration Guide

After you configure broadcast/unknown unicast/unknown multicast storm control on an interface, if the broadcast/unknown

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

Contact Us

Continue your research online:

Website: <https://alfa-pro.co.za>

Technical inquiry: <https://alfa-pro.co.za/contact.html>

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

