

H3C Cable Management Stand Installation



Overview

Support You can purchase one cable management frame for the switch and install it on the rack posts immediately above or below the switch Support H3C UniSe.

Key Takeaways

Install the H3C cable management stand by securing mounting brackets to the switch chassis, attaching bottom support rails to the rack, and aligning the stand for proper cable routing and ventilation.Safety and Preparation

Before installation, ensure the following:

- Power Off: Disconnect all power cords from the switch to prevent electrical hazards .
- ESD Protection: Wear an ESD wrist strap when handling modules or power supplies to avoid electrostatic damage .
- Environment: Install indoors in a well-ventilated area, free from moisture, dust, and corrosive gases .
- Tools: Use user-supplied M4 and M6 screws, a screwdriver, and optionally a torque wrench for precise tightening .

Mounting the Cable Management Stand

- Attach Mounting Brackets to the Switch:
- Place the wide side of each bracket against the designated chassis position.
- Align the bracket holes with the chassis screw holes.

- Secure using the provided M4 screws (recommended torque: 12 kgf-cm), .
- Install Bottom Support Rails in the Rack:
- Mark the cage nut installation holes on the rack posts.
- Insert user-supplied cage nuts into the marked holes.
- Align the bottom support rail with the rack posts and secure using M6 screws (recommended torque: 30 kgf-cm), .
- Attach the Switch to the Rack:
- Lift the switch and align the mounting brackets with the installed support rails.
- Secure the brackets to the rails using screws, ensuring the switch is level and stable .

Cable Management Stand Installation

- Position the Stand: Place the cable management stand in front of or above the switch, depending on rack configuration.
- Secure the Stand: Attach the stand to the rack posts using screws or brackets provided with the stand. Ensure it is firmly fixed to prevent movement.
- Route Cables: Organize network and power cables through the stand's guides or rings, maintaining proper bend radius to avoid damage.
- Ventilation: Ensure that the stand does not obstruct airflow to the switch vents .

Final Checks

- Verify all screws are tightened to recommended torque.
- Confirm that cables are neatly routed and do not block airflow.
- Power on the switch and check for proper operation. Following these steps ensures a secure, organized, and safe installation of the H3C cable management stand, protecting both equipment and personnel while maintaining optimal network performance .

Article Content

Support

You can purchase one cable management frame for the switch and install it on the rack posts immediately above or below the switch

Support

H3C UniServer B16000 Blade Server Chassis Hardware Options Installation and Replacement Videos-6W100 01-Install slide rails 02

Support

H3C UniServer R4700 G5 Hardware Options Installation and Replacement Videos-6W100 01-Install standard, ball-bearing, or short

H3C S5560X-HI SERIES INSTALLATION MANUAL Pdf

View and Download H3C S5560X-HI Series installation manual online. S5560X-HI Series switch pdf

H3C Racks & Stands User Manuals Download | ManualsLib

User manuals, H3C Racks & Stands Operating guides and Service manuals.

Support

Product References The Product References contains product-related technical documents and maintenance materials, including

H3C Switches Install Guide: AI Chat & PDF Access | Manualzz

The installation procedure is the same for PSR75-12A, PSR150-A1, and PSR150-D1 power modules. The following procedure uses

H3C S6850&S9850 Switches Install Guide + AI Chat | Manualzz

This guide provides instructions for installing the H3C S6850&S9850 switch series, covering rack mounting, grounding, fan and

H3C S7500E Series Ethernet Switches Installation Manual (V1.07)

Introduces how to install and remove power modules, cards, fans, mounting ears, cable management bracket, CF card, and air filters

RTM Installation Manual

Read the installation and operating instructions before installing and commissioning the equipment. These instructions must be

H3C S5560X-HI SERIES INSTALLATION MANUAL Pdf

View and Download H3C S5560X-HI Series installation manual online. S5560X-HI Series switch pdf

Support

H3C UniServer R4900 G5 Hardware Options Installation and Replacement Videos-6W101 01-Install standard, ball-bearing, or short

Support

H3C UniServer R6700 G3 Hardware Options Installation and Replacement Videos-6W100 01-Install standard, ball-bearing, or short

Knowledge Base

As the data navigation entry for the company's full range of products, the data center mainly provides service documents such as

H3C SE-S5130 SERIES INSTALLATION MANUAL Pdf Download

Page 3 Preface H3C SE-S5130 Switch Series Installation Guide describes the installation, power-on, maintenance, and

Support

H3C UniServer R6900 G5 Hardware Options Installation and Replacement Videos-6W102 01-Install standard, ball-bearing, or short

Support

Table of Contents H3C UniServer R4900 G6 Ultra Hardware Options Installation and Replacement Videos-6W100 01-Install

Support

Attaching slide rails and cage nuts to the rack Installing slide rails Before you mount the router in a rack, install slide rails on the rack.

Support

Support As a leader in digital solutions, H3C supports fully integrated IT infrastructures in environments ranging from traditional

Support

H3C UniServer R4300 G3 Hardware Options Installation and Replacement Videos-6W100 01-Install standard, ball-bearing, or short

H3C B002 Mobile Stand Installation Guide-5PW103

About H3C Company Information Customer Stories Corporate Social Responsibility
Newsroom Events Partner Become a Partner

Support

To install the driver on other operating systems, see the installation guide in the
driver compression package named by the

Support

H3C S7500E Switch Series Installation Guide-6W109 00-Preface 01-Chapter 1
Preparing for Installation 02-Chapter 2 Installing the

Support

To install the driver on other operating systems, see the installation guide in the
driver compression package named by the

Support

H3C UniServer R4700 G5 Hardware Options Installation and Replacement
Videos-6W100 01-Install standard, ball-bearing, or short

H3C S5570S-EI Series High Performance Intelligent Ethernet Switch

H3C S5570S-EI series switches are a new generation of high-performance, high-port
density, high-security and easy-to-install

04-Chapter 4 Connecting Your Switch to the Network

After the switch is connected to the network, use the ping or tracert command to test
the network connectivity. For more information

Support

H3C UniServer R4900 G3 Hardware Options Installation and Replacement
Videos-6W101 01-Install standard, ball-bearing, or short

Support

H3C UniServer R4900 G5 Hardware Options Installation and Replacement
Videos-6W100 01-Install standard, ball-bearing, or short

Support

To install the driver on other operating systems, see the installation guide in the
driver compression package named by the

H3C S5560X-HI SERIES INSTALLATION MANUAL Pdf

View and Download H3C S5560X-HI Series installation manual online. S5560X-HI Series switch pdf

Support

H3C UniServer R4900 G5 Hardware Options Installation and Replacement Videos-6W101 01-Install standard, ball-bearing, or short

Support

H3C UniServer R6700 G3 Hardware Options Installation and Replacement Videos-6W100 01-Install standard, ball-bearing, or short

Knowledge Base

As the data navigation entry for the company's full range of products, the data center mainly provides service documents such as

H3C SE-S5130 SERIES INSTALLATION MANUAL Pdf Download

Page 3 Preface H3C SE-S5130 Switch Series Installation Guide describes the installation, power-on, maintenance, and

Support

H3C UniServer R6900 G5 Hardware Options Installation and Replacement Videos-6W102 01-Install standard, ball-bearing, or short

Support

Preparing for installation Server compatibility with CAS H3C CAS is a hardware-assisted virtualization system. To run H3C CAS, the

Support

For more information about login methods, see H3C S12500X-AF Switch Series Fundamentals Configuration Guide. Configuring the

Support

To install the driver on other operating systems, see the installation guide in the driver compression package named by the

Support

To install the driver on other operating systems, see the installation guide in the driver compression package named by the

Support

Table of Contents H3C UniServer R4900 G6 Ultra Hardware Options Installation and Replacement Videos-6W100 01-Install

Support

Attaching slide rails and cage nuts to the rack Installing slide rails Before you mount the router in a rack, install slide rails on the rack.

Support

Support As a leader in digital solutions, H3C supports fully integrated IT infrastructures in environments ranging from traditional

Support

H3C UniServer R4300 G3 Hardware Options Installation and Replacement Videos-6W100 01-Install standard, ball-bearing, or short

Support

You can purchase one cable management frame for the switch and install it on the rack posts immediately above or below the switch

Support

H3C UniServer B16000 Blade Server Chassis Hardware Options Installation and Replacement Videos-6W100 01-Install slide rails 02

Support

H3C UniServer R4700 G5 Hardware Options Installation and Replacement Videos-6W100 01-Install standard, ball-bearing, or short

H3C S5560X-HI SERIES INSTALLATION MANUAL Pdf

View and Download H3C S5560X-HI Series installation manual online. S5560X-HI Series switch pdf

H3C Racks & Stands User Manuals Download | ManualsLib

User manuals, H3C Racks & Stands Operating guides and Service manuals.

Support

Product References The Product References contains product-related technical documents and maintenance materials, including

H3C Switches Install Guide: AI Chat & PDF Access | Manualzz

The installation procedure is the same for PSR75-12A, PSR150-A1, and PSR150-D1 power modules. The following procedure uses

[H3C S6850&S9850 Switches Install Guide + AI Chat | Manualzz](#)

This guide provides instructions for installing the H3C S6850&S9850 switch series, covering rack mounting, grounding, fan and

[H3C S7500E Series Ethernet Switches Installation Manual \(V1.07\)](#)

Introduces how to install and remove power modules, cards, fans, mounting ears, cable management bracket, CF card, and air filters

[RTM Installation Manual](#)

Read the installation and operating instructions before installing and commissioning the equipment. These instructions must be

[Support](#)

You can purchase one cable management frame for the switch and install it on the rack posts immediately above or below the switch

[Support](#)

[H3C UniServer B16000 Blade Server Chassis Hardware Options Installation and Replacement Videos-6W100 01-Install slide rails 02](#)

[Support](#)

[H3C UniServer R4700 G5 Hardware Options Installation and Replacement Videos-6W100 01-Install standard, ball-bearing, or short](#)

[H3C S5560X-HI SERIES INSTALLATION MANUAL Pdf](#)

View and Download H3C S5560X-HI Series installation manual online. S5560X-HI Series switch pdf

[H3C Racks & Stands User Manuals Download | ManualsLib](#)

User manuals, H3C Racks & Stands Operating guides and Service manuals.

[Support](#)

Product References The Product References contains product-related technical documents and maintenance materials, including

[H3C Switches Install Guide: AI Chat & PDF Access | Manualzz](#)

The installation procedure is the same for PSR75-12A, PSR150-A1, and PSR150-D1 power modules. The following procedure uses

[H3C S6850&S9850 Switches Install Guide + AI Chat | Manualzz](#)

This guide provides instructions for installing the H3C S6850&S9850 switch series, covering rack mounting, grounding, fan and

H3C S7500E Series Ethernet Switches Installation Manual (V1.07)

Introduces how to install and remove power modules, cards, fans, mounting ears, cable management bracket, CF card, and air filters

RTM Installation Manual

Read the installation and operating instructions before installing and commissioning the equipment. These instructions must be

Contact Us

Continue your research online:

Website: <https://alfa-pro.co.za>

Technical inquiry: <https://alfa-pro.co.za/contact.html>

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

